

PORTABLE
FORCED AIR HEATERS
“USER’S MANUAL”

DuraHeat®



MODEL:

DFA-45

DFA-70

DFA-125



LISTED

Before the first use of this heater, please read this USER’S MANUAL very carefully. This USER’S MANUAL has been designed to instruct you as to the proper manner in which to assemble the heater, maintain the heater, store the heater, and most importantly, how to operate the heater in a safe and efficient manner. Please keep this manual for future reference.

World Marketing of America, Inc.
12256 William Penn Hwy
Mill Creek, PA 17060
1- 800 - 776 - 9425 (9AM - 4PM EST)
MON.- FRI. ONLY
www.yourheater.com

**NEVER LEAVE THE HEATER
UNATTENDED WHILE BURNING!**

DANGER - IMPROPER USE OF THIS HEATER CAN RESULT IN SERIOUS INJURY OR DEATH FROM BURNS, FIRE, EXPLOSION, ELECTRICAL SHOCK AND/OR CARBON MONOXIDE POISONING.

WARNINGS:

1. RISK OF INDOOR AIR POLLUTION!

- **Use this heater only in well ventilated areas.** Provide at least a three-square foot (2,800 sq. cm.) opening of fresh outside air for each 100,000 BTU/hr. of heater rating.
- People with breathing problems should consult a physician before using the heater.
- **Carbon monoxide poisoning:** Early signs of carbon monoxide poisoning resemble the flu, with headaches, dizziness and/or nausea. If you have these signs, the heater may not be working properly. **Get fresh air at once!** Have the heater serviced. Some people are more affected by carbon monoxide than others. These include pregnant women, persons with heart or lung disease or anemia, those under the influence of alcohol, or those at high altitudes.
- Never use this heater in living or sleeping areas.

2. RISK OF BURNS/FIRE/EXPLOSION!

- **NEVER** use any fuel other than 1-K kerosene in this heater. #1 fuel oil is the only acceptable substitute.
- **NEVER** use fuel such as gasoline, benzene, paint thinners or other oil compounds in this heater. **(RISK OF FIRE OR EXPLOSION)**
- **NEVER** use this heater where flammable vapors may be present.
- **NEVER** refill the heaters fuel tank while heater is operating or is still hot.
- This heater is **EXTREMELY HOT** while in operation. Keep all combustible materials away from heater. **Minimum Clearances:** Outlet: 8 feet (250cm) / Sides, top and rear: 4 feet (125cm)
- **NEVER** block air inlet (rear) or air outlet (front) of heater.
- **NEVER** use duct work in front or behind of heater.
- **NEVER** move or handle heater while still hot.
- **NEVER** transport heater with fuel in it's tank.
- When used with an optional thermostat heater may start at any time.
- **ALWAYS** locate heater on a stable and level surface.
- **ALWAYS** keep children and animals away from heater.
- Bulk fuel storage should be a minimum of 25 ft. from heaters, torches, portable generators or other sources of ignition. All fuel storage should be in accordance with federal, state or local authorities having jurisdiction.

3. RISK OF ELECTRIC SHOCK!

- Use only the electrical power (voltage and frequency) specified on the model plate of the heater.
- Use only a three-prong, grounded outlet and extension cord.
- **ALWAYS** install the heater so that it is not directly exposed to water spray, rain, dripping water or wind.
- **ALWAYS** unplug the heater when not in use.

CALIFORNIA RESIDENTS: This heater produces carbon monoxide, which is listed by the State of California as a reproductive toxin under Proposition 65.

MASSACHUSETTS RESIDENTS: Massachusetts state law prohibits the use of this heater in any building which is used in whole or in part for human habitation. Use of this heating device in Massachusetts requires local fire dept. permit (M.E.L.C. 148, Section 10A.)

CANADIAN RESIDENTS: Use of this heater shall be in accordance with authorities having jurisdiction and CSA Standard B139.

NEW YORK CITY RESIDENTS: For use only at construction sites in accordance with applicable NYC codes under NYC FD certificate of approval #5034 and 5037.

**NEVER LEAVE THE HEATER
UNATTENDED WHILE BURNING!**

CONTENTS OF USER'S MANUAL

<u>ITEM</u>	<u>PAGE #</u>
PRECAUTIONS - SAFETY GUIDE	1
1. INTRODUCTION	2
2. FEATURES	2
3. UNPACKING AND ASSEMBLY	4
4. KEROSENE (1-K OR NO. 1 FUEL OIL)	6
5. OVERVIEW OF HEATER DESIGN	7
6. FUELING YOUR HEATER	8
7. OPERATION	8
8. LONG TERM STORAGE OF YOUR HEATER	9
9. MAINTENANCE	10
10. REPLACING FUSE	13
11. TROUBLE SHOOTING GUIDE	14
12. WIRING DIAGRAM	15
13. SPECIFICATIONS	16
14. EXPLODED PARTS DRAWING	17
15. PARTS LIST	18

1. INTRODUCTION

Please read this USER'S MANUAL carefully. It will show you how to assemble, maintain, and operate the heater safely and efficiently to obtain full benefits from its many built-in features.

2. FEATURES




Figure 1. DFA-45 / DFA-70 MODEL

**NEVER LEAVE THE HEATER
UNATTENDED WHILE BURNING!**




Figure 2. DFA-125 MODEL

**NEVER LEAVE THE HEATER
UNATTENDED WHILE BURNING!**

3. UNPACKING AND ASSEMBLY

1. REMOVE THE HEATER AND ALL PACKING MATERIALS FROM THE BOX. (Fig. 3 and 4)

NOTE : Save the shipping carton and packing materials for future storage.

	DFA-45	DFA-70	DFA-125
Wheel Support Frame	No	No	Yes
Wheels	No	No	Yes
Handle	Yes	Yes	Yes
Axle	No	No	Yes
Hardware Kit:HW-KFA1000	Yes	Yes	No
Hardware Kit:HW-KFA1010	No	No	Yes

Figure 3. DFA-45 / DFA-70 MODEL





Figure 4. DFA-125 MODEL



**NEVER LEAVE THE HEATER
UNATTENDED WHILE BURNING!**

2. ASSEMBLY

A. For DFA-45/DFA-70 Models Only (Figure 5)

Tools Required

- Medium Phillips Screwdriver

1. Lift front guard for arrow direction and make sure that guard's wedged portion fits into the slit hole in the upper shell and faces the hot air outlet.
2. Align the holes in the upper shell with the 2 mounting holes on the handle as shown in Figure 5.
3. Insert screws into the holes in the handle and tighten each screw.




Figure 5

B. For DFA-125 model only (Figure 6)

These models are furnished with wheels and handles. Wheels, handles, and the mounting hardware are found in the shipping carton.

Tools Required

- Medium Phillips Screwdriver
- 5/16" (M5) Open or Adjustable Wrench, Use Us(Inch) Screws Nut.
- Long Nose Pliers

1. Slide axle through wheel support frame. Install wheels on axle.

NOTE: When installing wheels, point extended hub of wheels toward wheel support frame (see Figure 6)

2. Place flat washers and split pin on axle ends and bend split pins with long nose pliers to secure.
3. Place heater on wheel support frame. Make sure air inlet end (rear) of heater is over wheels. Align the holes on fuel tank flange with holes on wheel support frame.
4. Position the handle on top of fuel tank flange. Insert screws through handles, fuel tank flange, and wheel support frames as shown in Figure 6 and attach nut finger tight after each screw is inserted.
5. After all screws are inserted, tighten nuts firmly.

CAUTION: DO NOT OPERATE heater without support frame assembled to tank.

**NEVER LEAVE THE HEATER
UNATTENDED WHILE BURNING!**




Figure 6. Wheel and Handle Assembly, DFA-125 MODEL

NOTE : Heater should be inspected before each use, and at least annually by a qualified service person.

4. KEROSENE (1-K)

For optimal performance of this heater, it is strongly suggested that 1-K kerosene be used. 1-K kerosene has been refined to virtually eliminate contaminants, such as sulphur. Which can cause a rotten egg odor during the operation of the heater. However, #1 or #2 fuel oil (diesel fuel) may also be used if 1-K kerosene is not available. Be advised that these fuels do not burn as clean as 1-K kerosene, and care should be taken to provide more fresh air ventilation to accommodate any added contaminants that may be added to the heated space.

KEROSENE SHOULD ONLY BE STORED IN A BLUE CONTAINER THAT IS CLEARLY MARKED “KEROSENE”. NEVER STORE KEROSENE IN A RED CONTAINER.

Red containers are associated with gasoline.

NEVER store kerosene in the living space. Kerosene should be stored in a well ventilated place outside the living area.

NEVER use any fuel other than 1-K kerosene (#1 fuel oil is an acceptable substitute.)

NEVER use fuel such as gasoline, benzene, alcohol, white gas, camp stove fuel, paint thinners, or other oil compounds in this heater. These are volatile fuels that can cause an explosion or uncontrolled flames.

NEVER store kerosene in direct sunlight or near a source of heat.

NEVER use kerosene that has been stored from one season to the next. Kerosene deteriorates over time.

“OLD KEROSENE” WILL NOT BURN PROPERLY IN THIS HEATER.

**NEVER LEAVE THE HEATER
UNATTENDED WHILE BURNING!**

5. OVERVIEW OF HEATERS DESIGN

Fuel System: This heater is equipped with an electric air pump that forces air through the air line connected to the fuel intake and then through a nozzle in the burner head. When the air passes in front of the fuel intake it causes fuel to rise from the tank and into the burner nozzle. This fuel and air mixture is then sprayed into the combustion chamber in a fine mist.

“Sure Fire Ignition”: The electronic ignitor sends voltage to a specially designed spark plug. The spark plug ignites the fuel and air mixture described above.

The Air System: The heavy duty motor turns a fan that forces air into and around the combustion chamber. Here the air is heated and then forced out the front of the heater.

The Safety System:

A. Temperature Limit Control: This heater is equipped with a Temperature Limit Control designed to turn off the heater should the internal temperature rise to an unsafe level. If this device activates and turns your heater off it may require service.


MODELS	Internal Shut-Off Temp. Plus/Minus 10 Degrees	Reset Temperature Plus/Minus 10 Degrees
DFA-125	230°F/110°C	194°F/90°C
DFA-45/DFA-70	176°F/80°C	122°F/50°C

Once the temperature falls below the reset temperature you will be able to start your heater.

B. Electrical System Protection: This heaters electrical system is protected by a fuse mounted to the PCB Assembly that protects it and other electrical components from damage. If your heater fails to operate check this fuse first and replace as needed.

FUSE TYPE:	All Models	125 volt / 8 amps
-------------------	------------	-------------------

C. Flame-Out Sensor: Utilizes a photocell to monitor the flame in burn chamber during normal operation. It will cause the heater to shut-off should the burner flame extinguish.



**NEVER LEAVE THE HEATER
UNATTENDED WHILE BURNING!**

6. FUELING YOUR HEATER

NEVER FILL THE HEATER FUEL TANK IN THE LIVING SPACE: FILL THE TANK OUTDOORS.

DO NOT OVERFILL YOUR HEATER AND BE SURE HEATER IS LEVELED.

IMPORTANT NOTICE REGARDING FIRST IGNITION OF HEATER:

The first time you light the heater, it should be done outdoors. This allows the oils, etc. used in manufacturing the heater to burn off outside.

WARNING!!: NEVER REFILL HEATER FUEL TANK WHEN HEATER IS OPERATING OR STILL HOT.

7. OPERATION

A.) VENTILATION

RISK OF INDOOR AIR POLLUTION/USE HEATER ONLY IN WELL VENTILATED AREAS.

Provide a fresh air opening of at least three square feet (2800 sq. cm) for each 100,000 BTU/Hr. rating. Provide extra fresh air if more heaters are being used.

Example:

A DFA-125 heater requires one of the following:

- a two-car garage door raised six inches (15.24 cm)
- a single-car garage door raised nine inches (22.86 cm)
- two, thirty-inch (76.20 cm) windows raised twelve inches (30.48 cm)

B.) OPERATION

TO START HEATER

1. Fill fuel tank with kerosene or No. 1 fuel oil.
2. Attach fuel cap.
3. Plug power cord of heater into three-prong, grounded extension cord. Extension cord must be at least six feet long.

Extension Cord Wire Size Requirements

- 6 to 10 feet (1.8 to 3 meters) long, use 18 AWG conductor.
- 11 to 100 feet (3.4 to 30.5 meters) long, use 16 AWG conductor.
- 101 to 200 feet (30.8 to 61 meters) long, use 14 AWG conductor.

4. Push power switch to "on" position, power indicator lamp will light and heater will start.




Figure 7. DFA-45/70/125 MODELS

NOTICE: The major electrical components of this heater are protected by a safety fuse mounted to the PCB board. If your heater fails to start, check this fuse first and replace as necessary. You should also check your power source to insure that proper voltage and frequency are being supplied to the heater.

**NEVER LEAVE THE HEATER
UNATTENDED WHILE BURNING!**

TO STOP HEATER

1. Turn switch to “OFF” and unplug power cord.

TO RESTART HEATER

1. Wait 10 seconds after stopping heater.
2. Repeat steps under to start heater.

8. LONG TERM STORAGE OF YOUR HEATER

FUEL TANK DRAIN

1. Drain fuel tank through fuel cap opening. (For DFA-45/70 Models Only)
2. Remove drain plug from rear bottom side of fuel tank by pulling plug grip downward and drain.
(For DFA-125 Model Only. See Figure 8)
3. Using a small amount of kerosene, swirl and rinse the inside of the tank.
NEVER mix water with the kerosene as it will cause rust inside the tank.
Pour the kerosene out making sure that you remove it all.
IMPORTANT : Do not store kerosene over summer months for use during next heating season.
Using old fuel could damage heater.
4. Reinstall fuel cap. Properly dispose of old and dirty fuel. (For DFA-45/65 Models Only)
5. Reinstall Drain Plug as follows. (For DFA-125 Model Only. See Figure 9)
 - Insert plug's seal head fully into drain hole so that flange is flush to tank's bottom.
 - Insert seal cap fully into head hole so that cap flange is flush to head flange.




Figure 8




Figure 9

IMPORTANT : Reinstall plug fully into hole in tank, Otherwise it will not seal completely.

6. Store heater in dry well ventilated area. Make sure storage place is free of dust and corrosive fumes.
7. Store the heater in the original box with the original packing material and keep the USER'S MANUAL with the heater.

**NEVER LEAVE THE HEATER
UNATTENDED WHILE BURNING!**

9. MAINTENANCE

WARNING!! : NEVER SERVICE HEATER WHILE IT IS PLUGGED IN OR WHILE HOT!

USE ORIGINAL EQUIPMENT REPLACEMENT PARTS. Use of third party or other alternate components will void warranty and may cause unsafe operating conditions.

A.) FUEL TANK

FLUSH EVERY 200 HOURS OF OPERATION
OR AS NEEDED (SEE STORAGE, PAGE 9)

B.) AIR INTAKE FILTER

WASH AND DRY WITH SOAP AND WATER
EVERY 500 HOURS OF OPERATION OR AS
NEEDED.

- Remove screws along each side of heater using medium phillips screwdriver.
- Lift upper shell off.
- Remove fan guard.
- Wash or replace air intake filter.
- Reinstall fan guard and upper shell.




Figure 10

C.) AIR OUTPUT FILTER, LINT FILTER

REPLACE EVERY 500 HOURS OF
OPERATION OR ONCE A YEAR.

- Remove upper shell and fan guard (See Air Intake Filter).
- Remove end filter cover screws using medium phillips screwdriver.
- Remove end filter cover.
- Replace air output and lint filter.
- Reinstall end filter cover.
- Reinstall fan guard and upper shell.




Figure 11

D.) FAN BLADES

CLEAN EVERY SEASON OR AS NEEDED.

- Remove upper shell (See Air Intake Filter).
- Use M6 allen wrench to loosen set screw which holds fan blade to motor shaft.
- Slip fan blade off motor shaft.
- Clean fan blade using a soft cloth moistened with kerosene or solvent.
- Dry fan blade thoroughly.
- Reinstall fan blade on motor shaft. Place fan blade hub flush with end of motor shaft.
- Place set screw on flat of shaft. Tighten set screw firmly (40-50 inch-pounds/4.5-5.6 N-m).
- Reinstall upper shell.




Figure 12

**NEVER LEAVE THE HEATER
UNATTENDED WHILE BURNING!**

E.) NOZZLE

REMOVE DIRT IN NOZZLE AS NEEDED
(SEE PAGE 13).

- Remove upper shell (See page 9).
- Remove fan blade (See page 10).
- Remove fuel and air line hoses from burner head.
- Remove ignitor wire from spark plug.
- Remove three screws using medium phillips screwdriver and remove burner head from combustion chamber.
- Remove spark plug from burner head using medium phillips screwdriver.
- Carefully remove nozzle from burner head using 5/8" socket wrench.
- Blow compressed air through face of nozzle. (this will remove any dirty in nozzle)
- Reinstall nozzle into burner head and tighten firmly. (80~110 inch-pounds)
- Install spark plug in burner head.
- Attach burner head to combustion chamber.
- Attach ignitor wire to spark plug.
- Attach fuel and air line hoses to burner head.
- Reinstall fan blade and upper shell.




Figure 13

F.) SPARK PLUG

CLEAN AND REGAP EVERY 600 HOURS
OPERATION OR REPLACE AS NEEDED.

- Remove upper shell (See page 10).
- Remove fan (See page 10).
- Remove ignitor wire from spark plug.
- Remove spark plug from burner head using medium phillips screwdriver.
- Clean and regap spark plug electrodes to 3.5mm gap. (0.138")
- Install spark plug in burner head.
- Attach ignitor wire to spark plug.
- Reinstall fan and upper shell.




Figure 14

G.) PHOTOCELL

CLEAN PHOTOCELL ANNUALLY OR AS NEEDED.

- Remove upper shell (See page 10).
- Remove fan (See page 10).
- Remove photocell from it's mounting.
Clean photocell lens with cotton swab.
- TO REPLACE : Remove side cover near on/off switch.
- Disconnect wires from circuit board and remove photocell.
- Install new photocell and attach wires to circuit board.
- Replace fan and upper shell.




Figure 15

**NEVER LEAVE THE HEATER
UNATTENDED WHILE BURNING!**

H.) FUEL FILTER

CLEAN OR REPLACE TWICE A HEATING SEASON OR AS NEEDED.

- Remove side cover screws using medium phillips screwdriver.
- Remove side cover.
- Pull fuel line off fuel filter neck.
- Turn fuel filter 90° to counterclockwise and pull to remove(DFA-45/70 models).
- Turn fuel filter 90° to clockwise and pull to remove(DFA-125 model).
- Wash fuel filter with clean fuel and replace in tank.
- Attach fuel line to fuel filter neck.
- Reinstall side cover.






Figure 16

I.) PUMP PRESSURE ADJUSTMENT

- Remove pressure gauge plug from end filter cover.
- Install accessory pressure gauge.
- Start heater (See Operation, page 8)
- Adjust pressure (Using a flat blade screwdriver)
 - Turn relief valve to right to increase pressure.
 - Turn relief valve to left to decrease pressure.
 Set pump pressure as noted below correct for pressure for each model.
- Stop heater (See Operation, page 8)
- Remove pressure gauge. Replace pressure gauge plug in end filter cover.



MODEL	PUMP PRESSURE
DFA-45	2.8 psi
DFA-70	3.7 psi
DFA-125	5.5 psi

NOTE : USE ONLY ORIGINAL EQUIPMENT REPLACEMENT PARTS.

Use of alternate or third party components will void any warranty and may cause unsafe operation condition.

**NEVER LEAVE THE HEATER
UNATTENDED WHILE BURNING!**

10. REPLACING FUSE

NOTICE : This heater is fuse protected.

If your heater fails to ignite, DO NOT RETURN YOUR HEATER TO THE STORE.

Please follow the simple instruction below to inspect and change the fuse.

PROCEDURE FOR REPLACING FUSE

⚠ WARNING : SHOCK HAZARD

To prevent personal injury, unplug the power cord before replacing fuse.


1. Unplug heater.
2. Remove side cover screws using medium phillips screw driver.
3. Remove fuse from fuse holder.(See Figure)
4. Replace fuse with enclosed fuse.

⚠ WARNING : FIRE HAZARD

To avoid fire, Do not substitute with a higher or lower current rating.

5. Replace side cover.

NOTE : Specified fuse rating : AC 125/8A



**NEVER LEAVE THE HEATER
UNATTENDED WHILE BURNING!**


11. TROUBLE SHOOTING GUIDE

TROUBLE	POSSIBLE CAUSE	CORRECTIVE ACTION
Heater ignites but MAIN PCB assembly shuts heater off after a short period of time. (Lamp is flickering)	<ol style="list-style-type: none"> 1. Wrong pump pressure 2. Dirty Air Output, Air Intake and Lint Filter 3. Dirty Fuel Filter 4. Dirt in Nozzle 5. Dirty Photocell Lens 6. Photocell Assembly not properly installed. (Not seeing the flame) 7. Bad electrical connection between photocell and MAIN PCB assembly 8. Defective photocell 	<ol style="list-style-type: none"> 1. See Pump Pressure Adjustment, page 12. 2. See Air Output, Air intake and Lint Filters, page 10. 3. See Fuel Filter, page 12. 4. See Nozzle, page 11. 5. Clean Photocell Lens, page 11. 6. Make sure photocell boot is properly seated in bracket, page 11. 7. Check electrical components See wiring diagram, page 14 8. Replace photocell, page 11
Heater will not ignite but motor runs for a short period of time. (Lamp is flickering)	<ol style="list-style-type: none"> 1. No fuel in tank 2. Wrong pump pressure 3. Carbon deposits on spark plug and/or improper gap 4. Dirty fuel filter 5. Dirt in nozzle 6. Water in fuel tank 7. Bad electrical connection between ignitor and MAIN PCB assembly 8. Ignitor wire is not attached to spark plug 9. Defective ignitor 	<ol style="list-style-type: none"> 1. Fill tank with kerosene 2. See Pump Pressure Adjustment, page 12. 3. See Spark Plug, page 11. 4. See Fuel Filter, page 12. 5. See Nozzle, page 11. 6. Flush fuel tank with clean kerosene, page 9. 7. Check electrical connections, See wiring diagram, page 14. 8. Attach ignitor wire to spark plug. See Spark Plug, page 11. 9. Replace ignitor.
Fan does not turn when heater is plugged in and power switch was in the “ON” position (Lamp is on or flickering)	<ol style="list-style-type: none"> 1. Bad electrical connection between motor and MAIN PCB assembly 	<ol style="list-style-type: none"> 1. Check electrical connections, See Wiring Diagram, page 15.
Heater will not turn-on (Lamp is off)	<ol style="list-style-type: none"> 1. Temperature limit safety device is overheated 2. No electrical power 3. Blown fuse 4. Bad electrical connection between temperature limit safety device and PCB board 	<ol style="list-style-type: none"> 1. Turn power switch to “OFF” and allow to cool (about 10 min.). Then turn power switch to “ON” position. 2. Check to insure heater cord and extension cord are plugged in. Check power supply. 3. Replace safety fuse in PCB board, page 13. 4. Check electrical connections. See Wiring Diagram, page 15.


**NEVER LEAVE THE HEATER
UNATTENDED WHILE BURNING!**

12. WIRING DIAGRAM

A) WIRING DIAGRAM (DFA-45 / DFA-70)




B) WIRING DIAGRAM (DFA-125)



**NEVER LEAVE THE HEATER
UNATTENDED WHILE BURNING!**

14. EXPLODED PARTS DRAWING

NOTE : SPECIFY MODEL NUMBER AND PART NUMBER WHEN ORDERING PARTS.



**NEVER LEAVE THE HEATER
UNATTENDED WHILE BURNING!**

15. PARTS LIST

KEY NO.	DESCRIPTION	PART NO.		
		DFA-45	DFA-70	DFA-125
1	Fuel Tank Assembly	280-1004-02	280-1004-02	280-1004-01
1-1	Drain Plug	-	-	3234-0059-00
2	Fuel Gauge	282-1001-01	282-1001-01	282-1001-00
3	Fuel Filter Assembly	287-4000-20	287-4000-20	287-4000-21
4	Fuel Cap	282-2000-90	282-2000-90	282-2000-90
5	Power Cord	140-9000-013	140-9000-013	140-9000-0133
6	Power Switch	110-9400-001	110-9400-001	110-9400-001
7	Display P.C.B. Assembly	160-9200-072	160-9200-072	160-9200-072
8	Lower Shell	3111-0209-00	3111-0209-00	3111-0210-00
9	Air Line	578-5100-55	578-5100-55	287-5100-53
10	Temperature Limit Control	154-9000-008	154-9000-008	154-9000-007
11	Combustion Chamber	2152-0064-00	2152-0042-00	2152-0045-00
12	Photocell Bracket	285-4104-91	285-4104-90	285-4104-90
13	Fuel Line	287-5100-50	287-5100-50	287-5100-52
14	Photocell Assembly	SP-KFA1007	SP-KFA1007	SP-KFA1007
15	Burner Head Assembly	See below	See below	See below
15-1	Nozzle	SP-KFA1026	SP-KFA1027	SP-KFA1003
15-2	Nozzle Seal Washer	285-8109-90	285-8109-90	285-8109-90
15-3	Nozzle Seal Spring	285-8110-00	285-8110-00	285-8110-00
15-4	Burner Head	284-7112-00	3531-0015-00	284-7112-11
15-5	Spark Plug	SP-KFA1008	SP-KFA1008	SP-KFA1009
15-6	Nipple	3541-0039-00	3541-0039-00	3541-0020-00
16	Motor and Pump Assembly	See below	See below	See below
16-1	Motor	111-9000-985	111-9000-985	111-9000-984
16-2	Pump Body	288-3100-00	288-3100-00	288-3100-00
16-3	Rotor Kit	SP-KFA1000	SP-KFA1000	SP-KFA1000
16-4	Blade	See SP-KFA1000	See SP-KFA1000	See SP-KFA1000
16-5	End Pump Cover	288-3100-10	288-3100-10	288-3100-10
16-6	Filter Kit	SP-KFA1005	SP-KFA1005	SP-KFA1005
16-7	Lint Filter	See SP-KFA1005	See SP-KFA1005	See SP-KFA1005
16-8	Output Filter	See SP-KFA1005	See SP-KFA1005	See SP-KFA1005
16-9	End Filter Cover	288-3100-40	288-3100-40	288-3100-40
16-10	Plug/Pump Adj. Kit	SP-KFA1006	SP-KFA1006	SP-KFA1006
16-11	Ball	See SP-KFA1006	See SP-KFA1006	See SP-KFA1006
16-12	Spring	See SP-KFA1006	See SP-KFA1006	See SP-KFA1006
16-13	Adj. Screw	See SP-KFA1006	See SP-KFA1006	See SP-KFA1006
16-14	Nipple	3541-0020-00	3541-0020-00	3541-0020-00
16-15	Capacitor	3820-0142-00	3820-0142-00	3820-0143-00

**NEVER LEAVE THE HEATER
UNATTENDED WHILE BURNING!**

15. PARTS LIST

KEY NO.	DESCRIPTION	PART NO.		
		DFA-45	DFA-70	DFA-125
17	Fan Assembly	283-1000-73	283-1000-72	283-1000-71
18	Ignitor	158-9100-001	158-9100-001	158-9100-007
19	Side Cover R	280-5102-922	280-5102-902	280-5103-012
20	Side Cover L	280-5102-915	280-5102-915	280-5103-022
21	Fan Guard	3221-0050-00	3221-0050-00	3221-0051-00
22	Main P.C.B. Assembly	215A-0019-00	215A-0019-00	215A-0019-00
22-1	Fuse	3920-0025-00	3920-0025-00	3920-0025-00
22-2	P.C.B. Supportor(R)	3221-0030-00	3221-0030-00	3221-0030-00
22-3	P.C.B. Supportor(L)	3221-0031-00	3221-0031-00	3221-0031-00
23	Clip Nut	285-4105-00	285-4105-00	285-4105-00
24	Upper Shell	3111-0213-00	3111-0213-00	3111-0214-00
25	Front Guard	3561-0066-00	3561-0066-00	3561-0066-00

**FOR TECHNICAL ASSISTANCE SEE YOUR LOCAL RETAILER OR
CONTACT US AT:**

Phone: 814-643-1775 Tech.: 814-643-2299

Fax: 814-643-3443

Email: techsvc@yourheater.com


or visit our website at www.yourheater.com

**NEVER LEAVE THE HEATER
UNATTENDED WHILE BURNING!**

15. PARTS LIST (WHEELS AND HANDLE)

1) DFA-45/70 MODELS

KEY NO.	DESCRIPTION	PART NO.		QTY
		DFA-45	DFA-70	
1	Handle	3231-0073-00	3231-0073-00	1
2	Hardware Kit	HW-KFA1000	HW-KFA1000	1



2) DFA-125 MODEL

KEY NO.	DESCRIPTION	PART NO.	QTY.
		DFA-125	
1	Handle	3551-0023-00	1
2	Wheel Support Frame	3551-0014-00	1
3	Axle	3541-0026-00	1
4	Wheel	2156-0003-00	2
5	Hardware Kit	HW-KFA1010	1
5-1	Screw(S)	-	2
5-2	Screw(L)	-	2
5-3	Flange Screw	-	4
5-4	Nut	-	8
5-5	Split Pin	-	2
5-6	Flat Washer	-	2

